

NEW APPLICATIONS - ADDITION TO GUIDE 2010-2

Car model	Body	Year	Type	Info	Ready packaged		Classic	Foot unit	Fitting kit	Art.No. new articles	EAN-code new articles	Extension kit	Sq. Bar	Alu bar	Locks	Date	
					ReadyFit			FlexiKit 2/ FlexiKit 3									
NEW APPLICATIONS																	
Audi	Q3		2011-		RR	RF23	RF23Alu			3703				T126	A126	Incl	2011-11-16
Audi	A6 Avant		2011-		RR	RF23	RF23Alu			3703				T126	A126	Incl	2011-11-16
Opel	Astra Sports Tourer		2009-		RR					3716	787036	7316177870364		T118	A118	Incl	2011-11-15
Vauxhall	Astra Sports Tourer		2009-		RR					3716	787036	7316177870364		T118	A118	Incl	2011-11-15
BMW	X1	SUV	2010-		RR					3713	787033	7316177870333		T126	A126	Incl	2011-11-15
Hyundai	i30	5dr	2007-		F	RF15										Incl	2011-11-23
Kia	Cee'd	5dr	2007-		F	RF15										Incl	2011-11-23
Mazda	3	5dr	2003-09		F	RF15										Incl	2011-11-23
Mazda	3	4dr	2004-09		F	RF15										Incl	2011-11-23
Mazda	3	5dr	2009-		F	RF15										Incl	2011-11-23
Mazda	3	4dr	2009-		F	RF15										Incl	2011-11-23
ReadyFit 21 & ReadyFit 21Alu																	
RF21 (Art.No.747021-EAN 7316177470212) - RF21Alu (Art.No.748021-EAN 7316177480211)																	
Citroën	C4 Picasso	MPV	2007-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Citroën	C4 Grand Picasso	MPV	2008-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Citroën	Picasso	MPV	2006-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Dodge	Journey	5dr Hatch	2008-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Fiat	Qubo	MPV	2009-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Lancia	Zeta	MPV	1995-02		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Mazda	CX9	5dr SUV	2007-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Mercedes	M Class (W164)	5dr 4x4	2005-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Mercedes	Vaneo	Van	2002-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Subaru	B9 Tribeca	5dr SUV	2007-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Subaru	Tribeca	5dr 4x4	2008-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Toyota	Highlander	5dr 4x4	2010-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Toyota	Landcr Amazon,100	5dr 4x4	1998-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Toyota	Landcruiser V8	5dr 4x4	2008-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Toyota	Landcruiser Prado	5dr 4x4	2010-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Volkswagen	Cross Touran	MPV	2011-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Volkswagen	Sharan	MPV	2010-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Volkswagen	Touareg	MPV	2010-		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18
Volkswagen	Touran	MPV	2003-10		RR	RF21	RF21Alu			3701	787020	7316177870203		T126	A126	Incl.	2011-10-18

A) not suitable for vehicles with high/full length sun roof RR) roof rails B) both load bars attached to the front door F) fixpoints T) profile in the roof *) also available in 2-packs

NEW APPLICATIONS - ADDITION TO GUIDE 2010-2

Car model	Body	Year	Type	Info	Ready packaged		Classic	Foot unit	Fitting kit	Art.No. new articles	EAN-code new articles	Extension kit	Sq. Bar	Alu bar	Locks	Date			
					ReadyFit			FlexiKit 2/ FlexiKit 3											
Volkswagen	Touran	MPV	2011-		RR	RF21	RF21Alu			3701		787020	7316177870203		T126	A126	Incl.	2011-10-18	
Volvo	V70 I	5dr Estate	1996-00		RR	RF21	RF21Alu			3701		787020	7316177870203		T126	A126	Incl.	2011-10-18	
ReadyFit 25 & ReadyFit 25Alu																			
RF25 (Art.No.747025-EAN 7316177470250) - RF25Alu (Art.No.748025-EAN 7316177480259)																			
Volvo	XC60	5dr 4x4	2008-		RR	RF25	RF25Alu			3711		787031	7316177870319		T126	A126	Incl.	2011-10-18	
Volvo	V60	5dr Estate	2011-		RR	RF25	RF25Alu			3711		787031	7316177870319		T126	A126	Incl.	2011-10-18	
BMW	X3	5dr 4x4	2010-		RR					3712		787032	7316177870326		T126	A126	Incl.	2011-07-01	
Opel	Astra	5dr Hatch	2009-		F					859/1		788591	7316177885917		T106	A106	No.501	2011-07-01	
Opel	Meriva	MPV	2010-		F					859/1		788591	7316177885917		T118	A118	No.501	2011-07-01	
Vauxhall	Astra	5dr Hatch	2009-		F					859/1		788591	7316177885917		T106	A106	No.501	2011-07-01	
Vauxhall	Meriva	MPV	2010-		F					859/1		788591	7316177885917		T118	A118	No.501	2011-07-01	
Audi	A1	3dr	2010-							BU1	FK208	786208	7316177862086	FK-X	T118	A118	Incl.	2010-11-16	
BMW	3-Serie Touring	Kombi	2010-		RR					3709		787029	7316177870296		T118	A118	Incl.	2011-05-17	
BMW	5-Serie Touring	Kombi	2010-		RR					3710		787030	7316177870302		T126	A126	Incl.	2011-05-17	
Chevrolet	Cruze	4dr	2010-							BU1	FK211	786211	7316177862116		T118	A118	Incl.	2011-01-26	
Chevrolet	Lacetti	Kombi	2004-		RR	RF20	RF20Alu	CRB1		3701					T118	A118	Incl.	2011-05-17	
Dacia	Duster		2010-		RR	RF20	RF20Alu			3701					T118	A118	Incl.	2010-11-02	
Ford	Fiesta	3dr	2008-							BU1	FK210	786210	7316177862109	FK-X	T118	A118	Incl.	2010-11-16	
Hyundai	Elantra	4dr	2007-10							BU1	FK212	786212	7316177862123		T126	A126	Incl.	2011-05-17	
Hyundai	ix35	MPV	2010-		RR					3708		787028	7316177870289		T126	A126	Incl.	2010-12-09	
Hyundai	Solaris	4dr	2010-							BU1	FK212	786212	7316177862123		T118	A118	Incl.	2011-05-17	
Kia	Sportage	MPV	2010-		RR					3708		787028	7316177870289		T126	A126	Incl.	2010-12-09	
Kia	Venga	5dr	2010-							BU1	FK205	786205			T118	A118	Incl.	2010-09-01	
Mazda	3	4dr	2009-		F					BU2 *	FK13				T118	A118	Incl.	2011-01-26	
Mazda	CX-9		2007-		RR					3701					T126	A126	Incl.	2011-01-26	
Mitsubishi	Pajero Sport	SUV	2010-		RR	RF20	RF20Alu			3701					T118	A118	Incl.	2011-05-17	
Nissan	Pixo	5dr	2009-							BU1	FK190				T118	A118	Incl.	2010-11-02	
Renault	Trafic		2001-		F					BU2 *	FK91				T159	A159	Incl.	2010-11-02	
Saab	9-3 (silver rails)	Wag./Est.	2009-		RR					3706					T118	A118	Incl.	2010-11-02	
Saab	9-3X (silver rails)		2009-		RR					3706					T118	A118	Incl.	2010-11-02	
Saab	9-5	4dr	2010-							BU1	FK206	786206	7316177862062		T126	A126	Incl.	2010-11-02	

A) not suitable for vehicles with high/full length sun roof RR) roof rails B) both load bars attached to the front door F) fixpoints T) profile in the roof *) also available in 2-packs

NEW APPLICATIONS - ADDITION TO GUIDE 2010-2

Car model	Body	Year	Type	Info	Ready packaged		Classic	Foot unit	Fitting kit	Art.No. new articles	EAN-code new articles	Extension kit	Sq. Bar	Alu bar	Locks	Date	
					ReadyFit			FlexiKit 2/ FlexiKit 3									
Subaru	Legacy	Wag./Est.	2009-		F			BU2 *	FK209	786209	7316177862093		T118	A118	Incl.	2010-11-16	
Suzuki	Grand Vitara	5dr	2007-		RR			3707		787027	7316177870272		T126	A126	Incl.	2010-10-18	
Toyota	Highlander		2010-		RR			3701					T126	A126	Incl.	2011-05-17	
Toyota	Land Cruiser Prado							3701					T126	A126	Incl.	2011-05-17	
Toyota	Verso		2009-		RR			3706					T126	A126	Incl.	2010-11-02	
Volvo	S60	4dr	2000-08					877					T118	A118	Incl.	2010-11-16	
Volvo	S60	4dr	2010-					BU1	FK207	786207	7316177862079		T126	A126	Incl.	2011-01-26	
Volvo	V60		2011-		RR			3711		787031	7316177870319		T126	A126	Incl.	2011-05-17	
Volvo	XC60		2008-		RR			3711		787031	7316177870319		T126	A126	Incl.	2011-05-17	
VW	Caddy		2010-		RR	RF20	RF20Alu	3701					T118	A118	Incl.	2010-11-02	
VW	Polo	4dr	2010-					BU1	FK195				T118	A118	Incl.	2011-05-17	
VW	Cross Touran		2011-		RR			3701					T126	A126	Incl.	2010-12-09	
VW	Polo	3dr	2009-					BU1	FK159			FK-X	T118	A118	Incl.	2010-11-02	
VW	Sharan		2010-		RR			3701					T126	A126	Incl.	2010-11-02	
VW	Touran		2011-		RR			3701					T126	A126	Incl.	2010-12-09	
CORRECTIONS (in red/bold) - the following information is correct																	
Volvo	V70 I	Kombi	97-00		RR	RF20	RF20Alu										Load bar is too short
Opel	Zafira	MPV	2007-		RR	RF24	RF24Alu		3704								Does not fit
Citroën	C5	5dr	01-04		F	RF15							T106	A106	Incl.	2011-02-10	
Toyota	Corolla		2007-					BU1	FK155				T106	A106	Incl.	2011-01-26	
Peugeot	Partner TePee	MPV	2007-					BU2	FK13				T126	A126	Incl.	No fit	

A) not suitable for vehicles with high/full length sun roof RR) roof rails B) both load bars attached to the front door F) fixpoints T) profile in the roof *) also available in 2-packs